



GOVI USA

Arktik 2000 Series Hot Gas Defrost Cycle Program Change

From every 4 Hours to every 2 Hours (or however often needed)

1. press set for more than 5 sec until you see "PAI"
2. press set shortly, you see "0"
3. press "up" until "222"
4. press set shortly, you see "dty"
5. press "up" until "dit"
6. press set shortly, you see "4"
7. press "down" until "2"
8. press set shortly, you see "dit"
9. press "I" (button right on top) shortly
10. you see the inside temp.

That's it!